

PF710 firmware upgrade process:

To upgrade the firmware:

- If you update Firmware, all settings of PF710 will be initialized. We recommend to backup the data before updating F/W.
- Do NOT disconnect the power adapter during Firmware update.

1. Copy the file (FWPF710.bin) to a device such as a USB flash drive or SD/SDHC/MMC/MS/CF memory card.
2. Insert the device into the slot of PF710.
3. Select Firmware upgrade from the Settings menu and press OK to start the firmware detection process. PF710 will automatically find the new firmware file.
4. If PF710 finds that a newer version of firmware is available, a "Yes / No" selection message will be shown. Use LEFT or RIGHT to select "Yes" and press OK to perform the system upgrade. If you do not want to upgrade, press "No" to return to the Settings menu.
5. After updating firmware success, the PF710 will reboot automatically.